



# Mixels


41560



 [LEGO.com](http://LEGO.com)

6150698


1




2




**3**




**4**



5




6







7




8







9




10




11




12



13



14



1




2




3




15



16




17







18




19



20




21









22




23




# 24




25





26





**1**




**2**



**3**



4



5



6





1x  
6056225



2x  
4211375



1x  
4211350



1x  
6094141



2x  
4613258



1x  
6117938



4x  
4655695



2x  
6046381



2x  
6043656



2x  
6093058



2x  
4141580



4x  
4624985



1x  
4160868



3x  
4655690



1x  
6133696



1x  
6004990



1x  
4210884



1x  
4538456



2x  
4515354



4x  
4566607



1x  
4666449



1x  
4211128



2x  
6132731



4x  
6029947



2x  
4161331



1x  
6030198



**Customer Service**

**Kundenservice**

**Service Consommateurs**

**Servicio Al Consumidor**

**LEGO.com/service or dial**



**00800 5346 5555 :**



**1-800-422-5346 :**



1x  
302226



2x  
292126



4x  
302324



2x  
4535740



2x  
4550348



2x  
4233484



2x  
371024



3x  
302024



1x  
301024



2x  
609121





**JAMZY**  
41560

**TAPSY**  
41561

**TRUMPSY**  
41562

**MIXIES**  
**MAX!**



[LEGO.com/mixels](http://LEGO.com/mixels)



SERIES  
**7**

WELCOME TO  
**MIXOPOLIS**



**PALADUM**  
41559



**CAMILLOT**  
41557



**TAPSY**  
41561



**TRUMPSY**  
41562



**KUFFS**  
41554



**JAMZY**  
41560



[LEGO.com/mixels](http://LEGO.com/mixels)



**BUSTO**  
41555



**TIKETZ**  
41556



**MIXADEL**  
41558





# club™



1 [LEGO.com/club](http://LEGO.com/club)



2



3

